



Key Override System (KOS) Installation Instructions

Before you install the Key Override System (KOS) and LockeyUSA Lock:

1. Any door or gate greater than 2" thick will need an extension kit (sold separately)
2. If using KOS on both sides of the door, you must use an extension kit (sold separately)

Handing on the KOS:

The Key Override System is preset for use on the exterior side of right-handed doors. If you have a left-handed door, you will need to change the handing of the KOS.

1. Remove the large center screw on the back side of the KOS using a #2 screwdriver.
2. Flip the cartridge so L is visible then replace the center screw.



Installing the KOS:

The Key Override System is compatible with the following LockeyUSA locks:

2200
2210/2210DC
2500
2830/2830DC
2835/2835DC
285P Keyless Panic Trim

Use the instructions provided with the lock, but make note of the following exceptions:

Support Pin:

Refer to lock instructions on how to install the support pin. However, when using the Key Override System, install the support pin into the back side of the KOS instead of the lock body as instructions direct.

Spindle Length:

Disregard the recommended spindle length from the lock instructions. Instead, hold the Inside Body to the door. Place Spindle through door and into the Inside Body as far as possible. Spindle should extend from the exterior of the door a minimum of 7/8" to a maximum of 1-1/8". *If needed, use the longer spindle and hex bolts included. If installing a 2830/2835, only use the spindle included with the lock.